


Mercedes 3.0 AMG engines



This product has been designed and manufactured to work correctly with installation as described in these instructions.

Failure to follow these instructions could result in damage to property, damage to the product and or potential injury.

It is very important that you read and understand these instructions thoroughly before installing this product.





- Ensure that your engine looks similar to the supplied photographs. (minor changes with ancillary components are to be expected, however if the engine looks nothing alike, please contact Bluespark Support.)
- Make sure that you have a good grasp of the operation of the connector clips and or locking tabs. - If the connectors you are trying to access are in an awkward place, it may be useful to try unplugging (and then re-inserting) a connector on the vehicle which is more easily accessible. Alternatively try plugging together the connectors on the Tuning Module itself.


Mercedes 3.0 AMG engines



Bluespark

- Remove the plastic engine cover, it is normally removed with a firm tug and your engine should look similar to the above photo.
- Familiarise yourself with the MAP and Boost sensors indicated in the above photo.

#### Mercedes 3.0 AMG engines



Bluespan

• Unplug the MAP Sensor connector (3 pin) by sliding back the grey release clip then pressing down the releasing clip and pulling back the connector.

• Insert the connector from the Tuning Module's wiring loom into the MAP Sensor.

• Insert the Vehicle's MAP Sensor connector into the corresponding connector on the Tuning Module's wiring loom.

• Secure the MAP wiring loom.

#### Mercedes 3.0 AMG engines





• Unplug the Boost Sensor connector (3 pin) by sliding back the grey release clip then pressing down the releasing clip and pulling back the connector.

• Insert the connector from the Tuning Module's wiring loom into the MAP Sensor.

• Insert the Vehicle's Boost Sensor connector into the corresponding connector on the Tuning Module's wiring loom.

• Secure the Boost wiring loom.



Route the tuning box wiring harness away from sources of heat (exhaust manifolds, EGR pipes, most stainless steel pipes) and also away from any rotating parts such as belts.

 Double check all connections are correct and firmly connected. If this is the case, start the vehicle and ensure there are no engine warning lights or error messages displayed.

If everything is as it should be, please feel free to take the vehicle out for a test drive and enjoy the added responsiveness and power added to your vehicle by the Tuning