





This product has been designed and manufactured to work correctly with installation as described in these instructions.

Failure to follow these instructions could result in damage to property, damage to the product and or potential injury.

It is very important that you read and understand these instructions thoroughly before installing this product.

#### **Included Contents:**

- Tuning Module
- Wiring Loom
- Fastening Ties
- Installation and User instructions
- Protective Bag For Module (prevents damage to unit casing)



#### Before installation:

- 1. Open the vehicle's bonnet
- 2. Remove the ignition key
- 3. Close and lock the doors
- Wait 5 minutes before removing any electrical plugs



Do not open the vehicle doors or unlock the vehicle while installation is in progress.

#### **Installation Location:**

The module should be installed between the vehicle's MAP and Boost sensors as shown in the diagram.

### Locating the Unit:

The unit itself should be mounted away from:




Sources of Extreme Heat



Sources of Vibration



Sources of Spray Water






Copyright 2022 - Bluespark Automotive Ltd. Unit 23A, Dubmire Ind. Est. DH4 5RJ, U.K. +44(0)191 385 9005




Jaguar/Land Rover 2.0 Ingenium Petrol



- Remove the plastic engine cover to expose the engine underneath. This usually just pulls off.
- Familiarise yourself with the locations of the connectors highlighted.
- Make sure that you have a good grasp of the operation of the connector clips. If
  the connectors you are trying to access are in an awkward place, it may be useful
  to try unplugging (and then re-inserting) a connector on the vehicle which is more
  easily accessible. Alternatively try plugging together the connectors on the Tuning
  Module itself.




Jaguar/Land Rover 2.0 Ingenium Petrol



- Remove the plastic engine cover. This usually pulls off with a firm tug. On certain models the cover is secured with bolts. If this is the case, remove the bolts and lift off the engine cover.
- You should be left with an engine that looks similar to the photo above.




Jaguar/Land Rover 2.0 Ingenium Petrol



- Unplug the MAP Sensor connector (4 pin) by sliding back the orange release clip, then press down the releasing button and pull back on the connector.
- Insert the connector from the Tuning Module's wiring loom into the MAP Sensor.
- Insert the Vehicle's MAP Sensor connector into the corresponding connector on the Tuning Module's wiring loom.
- Secure the MAP wiring loom and re-install the battery tray.

Jaguar/Land Rover 2.0 Ingenium Petrol







The boost sensor is located at the front of the engine on the boost pipe.

Most models will have sufficient space to access the boost sensor from the top of the engine. The boost senor can also be accessed from underneath the vehicle by removing the undertray.

- Unplug the Boost Sensor connector (4 pin) by sliding back the orange release clip, then press down the releasing button and pull back on the connector.
- Insert the connector from the Tuning Module's wiring loom into the Boost Sensor.
- Insert the Vehicle's Boost
   Sensor connector into the corresponding connector on the



### Jaguar/Land Rover 2.0 Ingenium Petrol

- Carefully re-install all engine covers that have been removed during the installation process.
- With the unit successfully installed please secure the unit and wiring loom within the engine bay, paying attention to the guidelines highlighted on Page 1.



Route the tuning box wiring harness away from sources of heat (exhaust manifolds, EGR pipes, most stainless steel pipes) and also away from any rotating parts such as belts.

Double check all connections are correct and firmly connected. If this is the case, start
the vehicle and ensure there are no engine warning lights or error messages displayed.

If everything is as it should be, please feel free to take the vehicle out for a test drive and enjoy the added responsiveness and power added to your vehicle by the Tuning Module.